



Blood Tracker 7 LED xLamp Blood Tracking Flashlight is made with pride in the USA. It is designed for hunters and bow hunters for tracking wounded animals in the night.

The Blood Tracker LED Flashlight is three flashlights in one. There is a white LED for general use, a red LED to preserve your night vision, and the Blood Tracker mode which uses green and white LEDs along with the flashing red LEDs.

This is a rechargeable LED Blood Tracker Flashlight with a sealed lead acid battery.

Instructions for Use

- Cycle modes using trigger on/off switch. Modes are (1) White; (2) Red; (3) Blood Tracker; and then repeat.
- Do not operate the flashlight during charging.
- Center white LED emitter flashing indicates low battery. It is time to charge the unit.
- Do not completely discharge the battery or battery life will be reduced.
- Do not submerge in water. Unit is splash resistant but not waterproof.
- **Do not unscrew head. Doing so voids your warranty.**
- **Not a toy! Keep out of reach of children.**
- Battery is fully recyclable and must be recycled in accordance with local and state guidelines.
- Glass lens can shatter if dropped. Use caution.

Instructions for Standard Charger



- This unit is provided with a standard external 120VAC charger.
- For 12VDC charging, use included cigarette lighter adapter charger.
- Charge for 24 hours prior to initial use.
- Red LED on handle indicates charging.
- Full charge from 120VAC adapter is 16-16 hours.
- Full charge from 12VDC adapter is 12 hours.
- Do not charge the battery for more than 24 hours.
- If unit is not used for two months, typically 4 hours of charging will be required.

Instructions for Smart Charger



- This option is the three stage smart Sealed Lead Acid charger.
- Smart charger accepts universal 90-250VAC input voltage
- Plug barrel connector into bottom of flashlight.
- Red LED on charger indicates high current charge.
- Green LED on charger indicates charge complete (low current trickle and top-off).
- Red LED on flashlight handle does not light with smart charger model.
- Full charge from smart charger is less than 4 hours.
- Smart charger can be left connected to flashlight to maintain good battery condition.
- If unit is not used for two months, typically 1 hour of charging will be required.

Questions? Please call us at 1-775-841-4490 or email Sales@TheLEDLight.com