power light source

Luxeon[™] Dental

Technical Data DS35

Luxeon™ is a revolutionary, energy efficient and ultra compact new light source, combining the lifetime and reliability advantages of Light Emitting Diodes with the brightness of conventional lighting.

Luxeon Dental Solutions include both Luxeon and Luxeon V alternatives, offering both a low and high power-curing source. Luxeon Dental is available in either the emitter or star form, allowing flexibility in curing system design.

Luxeon Dental products are selected from the peak wavelength range most effective for short curing times, and are produced to elevated minimum power levels to deliver the powerful short wavelength blue power required to reduce curing times while enabling handheld curing wands.

This revolutionary new product line is specifically tailored to the dental curing industry to provide the source most effective for this application.





Luxeon Dental is available in radiometric dental blue.

Features


- Highest Flux per LED in the world
- Very long operating life (up to100k hours)
- More Energy Efficient than Incandescent and most Halogen lamps
- Low voltage DC operated
- · Cool beam, safe to the touch
- Instant light (less than 100 ns)
- Fully dimmable
- No UV
- Superior ESD protection


Benefits


- Radiometric power levels and peak wavelength specifications matched to the response curves of many dental resins.
- Extreme radiometric power results in short curing times, <10 seconds for the Luxeon devices and on the order of 5 seconds for the Luxeon V devices.
- Low voltage DC operation allows for handheld cordless curing wand designs.
- Directed light from the source of the desired wavelength eliminates the need for inefficient color filters.
- Long life eliminates the need for bulb replacement




Mechanical Dimensions - Emitter










Batwing (Low Dome) - LXHL-BRD1


Notes:


- The anode side of the device is denoted by a hole in the lead frame. Electrical insulation between the case and the board is required - slug of device is not electrically neutral. Do not electrically connect either the anode or cathode to the slug.
- Drawings not to scale.
- All dimensions are in millimeters.
- All dimensions without tolerances are for reference only.

TOP VIEW



BOTTOM VIEW





_(4) Lens (2) Body

(1) Lead


Lambertian (High Dome) - LXHL-PRD5

- The anode side of the device is denoted by a hole in the lead frame. Electrical insulation between the case and the board is required - slug of device is not electrically neutral. Do not electrically connect either the anode or cathode to the slug.
- Drawings not to scale. 2.
- 3. All dimensions are in millimeters.
- All dimensions without tolerances are for reference only.


Mechanical Dimensions - Star

Luxeon Star





Batwing (Low Dome)




LXHL-MRD1

Notes:


- Slots in aluminum-core PCB for M3 or #4 mounting screw.
- Electrical interconnection pads labeled on the aluminum-core PCB with "+" and "-" to denote positive and negative, respectively. All positive pads are interconnected, as are all negative pads, allowing for flexibility in array interconnection.
- 3. Drawings not to scale.
- 4. All dimensions are in millimeters.

Luxeon V Star





Lambertian (High Dome)



LXHL-LRD5

- Slots in aluminum-core PCB for M3 or #4 mounting screw.
- Electrical interconnection pads labeled on the aluminum-core PCB with "+" and "-" to denote positive and negative, respectively. All positive pads are interconnected, as are all negative pads, allowing for flexibility in array interconnection.
- Electrical insulation between neighboring Stars is required – aluminum board is not electrically neutral.
- 4. Drawings not to scale.
- 5. All dimensions are in millimeters.

Part Number Matrix

PART NUMBER	BEAM PATTERN	Configuration	PRODUCT TYPE	DRIVE CURRENT
LXHL-BRD I	Batwing	EMITTER	LUXEON	350 MA
LXHL-MRD I	Batwing	STAR	LUXEON	350 MA
LXHL-PRD5	Lambertian	EMITTER	LUXEON V	700 MA
LXHL-LRD5	Lambertian	STAR	LUXEON V	700 MA

Radiometric Power Characteristics at 350mA, Junction Temperature, $T_J = 25^{\circ}C$

Luxeon	Configuration	Radiation Pattern	MINIMUM RADIOMETRIC POWER (MW) $\Phi_{ m V}^{[1,2]}$	Typical Radiometric Power (mW) $\Phi_{V}^{[2]}$
LXHL-BRD I	EMITTER	Batwing	115	40
LXHL-MRD I	Star	Batwing	115	40

Radiometric Power Characteristics at 700mA, Junction Temperature, $T_J = 25$ °C, Continued

Luxeon V	Configuration	Radiation Pattern	Minimum Radiometric Power (MW) $\Phi_V^{[1,2]}$	Typical Radiometric Power (MW) $\Phi_V^{[2]}$
LXHL-PRD5	EMITTER	Lambertian	500	600
LXHL-LRD5	Star	Lambertian	500	600

Optical Characteristics at 350 or 700mA, Junction Temperature, $T_{\perp} = 25^{\circ}C$

Part _	Pea	k Wavelend λΡ	этн ^[3]	SPECTRAL HALF-WIDTH ^[4] (NM)	TEMP COEFFICIENT OF DOMINANT WAVELENGTH (NM/C)	TOTAL INCLUDED ANGLE ^[5] (DEGREES)	VIEWING ANGLE ⁽⁶⁾ (DEGREES)
Number	MIN.	TYP.	Max.	$\Delta\lambda_{1/2}$	$\Delta\lambda_D/\Delta T_J$	$\theta_{0.90V}$	2θ 1/2
LXHL-BRD I [1]	450	460	470	20	0.04	0	0
LXHL-MRD I [1]	450	460	470	20	0.04	0	10
LXHL-PRD5 ^[2]	450	460	470	20	0.04	l 50	I 50
LXHL-LRD5 ^[2]	450	460	470	20	0.04	l 50	I 50

Notes (for both power tables):

- 1. Minimum radiometric power performance guaranteed within published operating conditions. Lumileds maintains a tolerance of \pm 10% on power measurements.
- 2. Luxeon types with even higher radiometric power levels will become available in the future. Please consult your Lumileds Authorized Distributor or Lumileds sales representative for more information.

- 1. Rated driver current of 350 mA for Luxeon Dental products.
- 2. Rated drive current of 700 mA for Luxeon V Dental products.
- 3. Lumileds maintains a tolerance of \pm 2nm for peak wavelength measurements.
- 4. Spectral width at ½ of the peak intensity.
- 5. Total angle at which 90% of total luminous flux is captured.
- 6. 0½ is the off axis angle from lamp centerline where the luminous intensity is ½ of the peak value.
- 7. All products built with Indium Gallium Nitride (InGaN).
- All power light sources represented here are IEC825 Class 2 for eye safety.

Electrical Characteristics at 350 or 700mA, Junction Temperature, $T_{..} = 25^{\circ}C$

<u>-</u>	Forwa	rd Voltage \		DYNAMIC RESISTANCE ^[4]	TEMPERATURE COEFFICIENT OF FORWARD VOLTAGE ^[5] (mV/°C)	THERMAL RESISTANCE, JUNCTION TO SLUG OR CASE ⁽⁶⁾
PART NUMBER	Min.	TYP.	Max.	$(\Omega) R_D$	$\Delta V_{F}/\Delta T_{J}$	(∘C/W) Rθ _{J-C}
LXHL-BRD I [1]	2.79	3.42	3.99	1.0	-2.0	l 5
LXHL-MRD I [1]	2.79	3.42	3.99	1.0	-2.0	l 7
LXHL-PRD5 ^[2]	5.43	6.84	7.83	I.O	-4.0	8
LXHL-LRD5 ^[2]	5.43	6.84	7.83	I.O	-4.0	I I

Notes:

- Rated drive current of 350 mA for Luxeon Dental products.
- 2. Rated drive current of 700 mA for Luxeon V Dental products.
- Lumileds maintains a tolerance of ± 0.06V on forward voltage measurements.
- Dynamic resistance is the inverse of the slope in linear forward voltage model for LEDs. See Figures 3a and 3b.
- 5. Measured between 25°C \leq TJ \leq 110°C at I_F = 350 or 700mA.
- Thermal resistance junction to slug for emitter products, junction to board for star products.

Absolute Maximum Ratings

Parameter	LXHL-BRD I LXHL-MRD I	LXHL-PRD5 LXHL-LRD5
DC FORWARD CURRENT (MA) [1]	350	700
PEAK PULSED FORWARD CURRENT (MA)	500	1000
AVERAGE FORWARD CURRENT (MA)	350	700
REVERSE VOLTAGE (V) [2]	> 5	> 5
LED JUNCTION TEMPERATURE (°C)	120	135
EMITTER STORAGE TEMPERATURE (°C)	-40 то + I 20	-40 то + I 20
Emitter Soldering Temperature (°C) [3]	260 FOR 5 SECONDS MAX	260 FOR 5 SECONDS MAX
STAR ALUMINUM-CORE PCB TEMPERATURE (°C)	100[4]	70 ^[4]
STAR STORAGE TEMPERATURE (°C)	-40 то +105	-40 то +105

- Proper current derating must be observed to maintain junction temperature below the maximum. For more information, consult the Luxeon Design Guide, available upon request.
- 2. Measured at $I_F = 100 \, \mu$ A. LEDs are not designed to be driven in reverse bias. All products are not sensitive to ESD damage ($\pm 16,000$ Volts by HBM condition).
- Measured at leads, during lead soldering and slug attach, body temperature must not exceed 120°C. Luxeon emitters cannot be soldered by general IR or Vapor-phase reflow, nor by wave soldering. Lead soldering is limited to selective heating of the leads, such as by hot-bar reflow, fiber focussed IR, or hand soldering. The package back plane (slug) may not be attached by soldering, but rather with a thermally conductive adhesive. Electrical insulation between the slug and the board is required. Please consult Lumileds' Application Brief AB10 on Luxeon Emitter Assembly Information for further details on assembly methods.
- Allowable MCPCB temperature to avoid exceeding maximum junction temperature at maximum V_f limit at rated DC forward current based on thermal resistance of Star assembly.

Wavelength Characteristics, $T_J = 25^{\circ}C$




Figure 1.
Relative Intensity vs. Wavelength.

Light Output Characteristics




Figure 2.
Relative Radiometric Power vs. Junction Temperature

6

Forward Current Characteristics, T_J = 25°C




Figure 3a. Forward Current vs. Forward Voltage for LXHL-BRD1 and LXHL-MRD1




Figure 4a. Relative Luminous Flux vs. Forward Current for LXHL-BRD1 and LXHL-MRD1 at $T_{\rm J} = 25^{\circ}{\rm C}$ maintained.




Figure 3b. Forward Current vs. Forward Voltage for LXHL-PRD5 and LXHL-LRD5




Figure 4b. Relative Luminous Flux vs. Forward Current for LXHL-PRD5 and LXHL-LRD5 at $T_J = 25^{\circ}\text{C}$ maintained.

Note:

Driving these high power devices at currents less than the test conditions may produce unpredictable results and may be subject to variation in performance. Pulse width modulation (PWM) is recommended for dimming effects.

Current Derating Curves - Luxeon




Figure 5.

Maximum Forward Current vs. Ambient
Temperature. Derating based on T_{JMAX} =
120 °C for LXHL-BRD1 and LXHL-MRD1.

Current Derating Curves - Luxeon V






Figure 6. Maximum Forward Current vs. Ambient Temperature. Derating based on T_{JMAX} = 135 °C for LXHL-PRD5 and LXHL-LRD5.

Representative Spatial Radiation Pattern

Batwing Radiation Pattern



Lambertian Radiation Pattern




Note:

For more detailed technical information regarding Luxeon radiation patterns, please consult your Lumileds Authorized Distributor or Lumileds sales representative.

Figure 7.
Representative Spatial Radiation Pattern for LXHL-BRD1 and LXHL-MRD1

Figure 8.
Representative Spatial Radiation Pattern for LXHL-PRD5 and LXHL-LRD5

Emitter Reel Packaging



END

START

User feed direction

GOMIO

EMPTY PICKETS

LIADED PICKETS

VITH TAPE


START

User feed direction

5 - 10

EMPTY PICKETS VITH

UNSEALED COVER TAPE



Buy it at:

The LED Light Inc Carson City NV 89705 Phone: 877-964-4215

e-mail: sales@TheLEDLight.com

www.TheLEDLight.com

Figure 9. Reel dimensions and orientation.

Figure 10. Tape dimensions.

- Luxeon emitters should be picked up by the body (not the lens) during placement. The inner diameter of the pick-up collet should be greater than or equal to 6.5 mm. Please consult Lumileds' Application Brief AB10 on Luxeon Emitter assembly information for further details on assembly methods.
- 2. Drawings not to scale.
- 3. All dimensions are in millimeters.
- 4. All dimensions without tolerances are for reference only.